

Downrigger Terminal Rigging

By John's Sporting Goods

Items Needed

- 300lb Braided Line
- #6 Beads
- 4/0 Snap Swivel
- Scotty Stopper Beads
- Tubing
- Super Glue



Step #1
Slide 2/#6 Beads
up the Downrigger Line

Step #2
Tie 12ft of 300lb
Braided Line to the
Downrigger Line
with a
Uni to Uni Knot

Step #3
Super Glue
the Knot

[Link to Tying
Uni to Uni Knot](#)

Step #6
Install Scotty
Red Stopper
Beads
on Each end of
the Tubing

Step #4
Slide the Tubing
on to the 300lb
Braided Line

The Tubing is Protection
for the Braided Line when
Snapping a Downrigger
Release to the Downrigger Line

Step #5
Tie the 300lb
Braid to Swivel
and Super Glue
the Knot

